

INSTALLATION INSTRUCTIONS

ELECTRICAL GAUGES W/DIGITAL DISPLAY

SMOKE LENS SERIES AMBER RED & WHITE LED

Air / Fuel Ratio Gauge (Narrowband)

OPENING CEREMONY

1

RED - BATTERY (+)
BLACK - BATTERY (-)
WHITE - NOTE
ORANGE - NOTE

POWER WIRE HARNESS

SENSOR WIRE HARNESS

BACK VIEW

2

METER

VISOR

BUFFER

METER CUP & HOLDER

3

52mm (60mm)

52mm (60mm)

4

52mm (60mm)

52mm (60mm)

5

6

SENSOR WIRE HARNESS

O2 SENSOR SIGNAL WIRE

ECU (ENGING COMPUTER UNIT)

BACK VIEW

7

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAYTIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE → CONNECT TO ACC ORANGE WIRE → NO CONNECT
AMBER RED SCALE	AMBER RED SCALE	WHITE WIRE → NO CONNECT ORANGE WIRE → CONNECT TO ACC
WHITE SCALE	AMBER RED SCALE	WHITE WIRE → CONNECT TO ACC ORNAGE WIRE → CONNECT TO PARKING LAMP
AMBER RED SCALE	WHITE SCALE	ORANGE WIRE → CONNECT TO ACC WHITE WIRE → CONNECT TO PARKING LAMP

8

Boost / Vacuum Gauge

OPENING CEREMONY

1

RED - BATTERY (+)
BLACK - BATTERY (-)
WHITE - NOTE
ORANGE - NOTE

POWER WIRE HARNESS

SENSOR WIRE HARNESS

BACK VIEW

2

METER

VISOR

BUFFER

METER CUP & HOLDER

3

52mm (60mm)

52mm (60mm)

4

5

BOOST INSTALLATION

BOOST / VACUUM SENSOR

Surge Tank

T-Fitting

Pressure Regulator

Air Filter

Hose

Boost Sensor

RED

WHITE

BLACK

6

SENSOR WIRE HARNESS

SHRINK TUBING (WHITE)

BLACK

RED

WHITE

BOOST / VACUUM SENSOR

7

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAYTIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE → CONNECT TO ACC ORANGE WIRE → NO CONNECT
AMBER RED SCALE	AMBER RED SCALE	WHITE WIRE → NO CONNECT ORANGE WIRE → CONNECT TO ACC
WHITE SCALE	AMBER RED SCALE	WHITE WIRE → CONNECT TO ACC ORNAGE WIRE → CONNECT TO PARKING LAMP
AMBER RED SCALE	WHITE SCALE	ORANGE WIRE → CONNECT TO ACC WHITE WIRE → CONNECT TO PARKING LAMP

8